TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 28750 Installation Instructions

7-Inch Lift Kit with Vertex Shocks for Suburban / Yukon XL 1500

Part number: 28750

trailfortress.com/rough-country-7-inch-lift-kit-28750

Scan for fitment, price and install help

9212987000

ROUGH COUNTRY SUSPENSION SYSTEMS®

1287BAG2

07-13 TAHOE/YUKON/SUB 7” KIT

Thank you for choosing Rough Country for your suspension needs. We appreciate your business!!

NOTICE **This kit will not fit vehicles equipped with electric steering or trucks with factory auto leveling or auto ride systems.**

Important note: Please refer to the instructions on the last page for trimming the tie rods. For alignment purposes, it will be necessary to trim/shorten the tie rod end to allow the front end alignment to be set properly.

Rough Country recommends a certified technician install this system. In addition to these instructions, professional knowledge of disassemble/reassembly procedures as well as post installation checks must be known. Attempts to install this system without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle.

Please read instructions before beginning installation. Check the kit hardware. Be sure you have all needed parts and know where they go.

PRODUCT USE INFORMATION

WARNING As a general rule, the taller a vehicle is, the easier it will roll. Seat belts and shoulder harnesses should be worn at all times. Avoid situations where a side rollover may occur. Generally, braking performance and capability are decreased when larger/heavier tires and wheels are used. Take this into consideration while driving. Do not add, alter, or fabricate any factory or after-market parts to increase vehicle height over the intended height of the Rough Country product purchased. Mixing component brands is not recommended.

Rough Country makes no claims regarding lifting devices and excludes any and all implied claims. We will not be responsible for any product that is altered. We will be happy to answer any questions concerning the design, function, and correct use of our products.

This kit is packaged as a leveling kit—raising the front 7” and the rear 6”.

Due to differences in manufacturing, dimension and inflated measurements, tire and wheel combinations should be test fit prior to installation.

TIRE	WHEEL	BACKSPACING	OFFSET
315/70 R17	17x9	-	+12 to +18mm
[1,2]295/70 R18	Factory 18	-	-
[2]315/65 R18	18x9	-	+12 to +18mm
[1,2]295/60 R20	Factory 20	-	-
[2]315/55 R20	20x9	-	+12 to +18mm
[1] Factory 18in & 20in wheels can be run but require 1/4in wheel spacers with 295 tires			
[2] Models equipped with Factory 18-inch or larger wheels must run 18-inch or larger wheels if changing to aftermarket wheels			

Optional kicker Bars Part #1262 are available for this kit. Please contact you local Rough Country Dealer for information.

NOTICE TO DEALER AND VEHICLE OWNER

WARNING Any vehicle equipped with any Rough Country product should have a “Warning to Driver” decal installed on the inside of the windshield or on the vehicle’s dash. The decal should act as a constant reminder for whoever is operating the vehicle of its unique handling characteristics.

INSTALLING DEALER - it is your responsibility to install the warning decal and forward these installation instructions on to the vehicle owner for review. These instructions should be kept in the vehicle for its service life.

By purchasing any item sold by Rough Country, LLC, the buyer expressly warrants that he/she is in compliance with all applicable Federal, State, and Local laws and regulations regarding the purchase, ownership, and use of the item. It shall be the buyers responsibility to comply with all Federal, State and Local laws governing the sales of any items listed, illustrated or sold. The buyer expressly agrees to indemnify and hold harmless Rough Country, LLC for all claims resulting directly or indirectly from the purchase, ownership, or use of the items.