TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 31004 Installation Instructions

Forged Track Bar for Ram 2500 4WD (2014-2025)

Part number: 31004

trailfortress.com/rough-country-track-bar-31004

Scan for fitment, price and install help

921310040

ROUGH COUNTRY SUSPENSION SYSTEMS®

Dodge 14-18 Ram 2500 Front Forged Track Bar

Thank you for choosing Rough Country for your off road needs.

Please read all the instructions before beginning the installation.

PRODUCT USE INFORMATION

We will be happy to answer any questions regarding our products by calling us @ 800-222-7023. Rough Country will not be responsible for any product that is altered.

KIT CONTENTS

1-Adj. Forged Track Bar

TOOLS NEEDED

19mm Socket
18mm Wrench
27mm Socket
Torque Wrench



INSTALLATION INSTRUCTIONS

1. Remove the track bar from the frame using a 27mm socket. Save hardware for reuse. **See Photo 1.**
2. Using a 27mm remove the track bar from the axle end. Save hardware for reuse. **See Photo 2.**



