TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 31005 Installation Instructions

31005

Part number: 31005

trailfortress.com/rough-country-track-bar-31005

Scan for fitment, price and install help

921310050

ROUGH COUNTRY SUSPENSION SYSTEMS®

Dodge 14-18 Ram 2500 Rear Forged Track Bar

Thank you for choosing Rough Country for your off road needs.

Please read all the instructions before beginning the installation.

PRODUCT USE INFORMATION

We will be happy to answer any questions regarding our products by calling us @ 800-222-7023. Rough Country will not be responsible for any product that is altered.

KIT CONTENTS

1-Adj. Forged Track Bar

TOOLS NEEDED

19mm Socket
18mm Wrench
21mm Socket
21mm Wrench
Torque Wrench



INSTALLATION INSTRUCTIONS

1. Using a 21mm socket remove the track bar from the axle end. Save hardware for reuse. . **See Photo 1.**
2. Remove the track bar from the frame using a 21mm socket and wrench. Save hardware for reuse. **See Photo 2.**





3. Remove the stock track bar from the vehicle.
4. Adjust the supplied forged track bar to the same length as the factory. **See Photo 3. This is only a starting point and the track bar may need further adjustment to center the front axle, depending on the amount of lift on the truck.**
4. Place the Rough County adjustable track bar in the factory mounts using the factory hardware. Do not tighten at this time. **See Photos 4 & 5**.
5. **It is important to center the vehicle over the axle to ensure proper tracking and alignment. If needed, turn the adjustment collar until the front axle is centered.**


PHOTO 3


PHOTO 4

⚠NOTICE Make sure the adjustment collar/clamps are orientated in the down position to keep from making contact with anything.

6. Tighten the adjustment collar clamps using an 18mm wrench and 19mm socket. **See Photo 6.**
7. Next torque the frame & axle mounts with a 21mm socket and wrench, torque to factory specs.


PHOTO 5


PHOTO 6

POST INSTALLATION

1. Check all fasteners for proper torque. Check to ensure there is adequate clearance between all rotating, mobile, fixed and heated members. Check steering for interference and proper working order.
2. Re torque all fasteners after 500 miles. Visually inspect components and re torque fasteners during routine vehicle service.

By purchasing any item sold by Rough Country, LLC, the buyer expressly warrants that he/she is in compliance with all applicable , State, and Local laws and regulations regarding the purchase, ownership, and use of the item. It shall be the buyers responsibility to comply with all Federal, State and Local laws governing the sales of any items listed, illustrated or sold. The buyer expressly agrees to indemnify and hold harmless Rough Country, LLC for all claims resulting directly or indirectly from the purchase, ownership, or use of the items.