TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 31005 Installation Instructions

31005

Part number: 31005

trailfortress.com/rough-country-track-bar-31005

Scan for fitment, price and install help

921310050

ROUGH COUNTRY SUSPENSION SYSTEMS®

Dodge 14-18 Ram 2500 Rear Forged Track Bar

Thank you for choosing Rough Country for your off road needs.

Please read all the instructions before beginning the installation.

PRODUCT USE INFORMATION

We will be happy to answer any questions regarding our products by calling us @ 800-222-7023. Rough Country will not be responsible for any product that is altered.

KIT CONTENTS

1-Adj. Forged Track Bar

TOOLS NEEDED

19mm Socket
18mm Wrench
21mm Socket
21mm Wrench
Torque Wrench



INSTALLATION INSTRUCTIONS

1. Using a 21mm socket remove the track bar from the axle end. Save hardware for reuse. . **See Photo 1.**
2. Remove the track bar from the frame using a 21mm socket and wrench. Save hardware for reuse. **See Photo 2.**



