Rough Country 32630 Installation Instructions

32630

Part number: 32630

trailfortress.com/rough-country-4-inch-lift-kit-32630

Scan for fitment, price and install help

92132600

ROUGH COUNTRY SUSPENSION SYSTEMS®

06-08 DODGE 1500 4” & 6” LIFT KIT

Thank you for choosing Rough Country for all your suspension needs.

Rough Country recommends a certified technician install this system. In addition to these instructions, professional knowledge of disassemble/reassembly procedures as well as post installation checks must be known. Attempts to install this system without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle.

Please read instructions before beginning installation. Check the kit hardware against the kit contents list. Be sure you have all needed parts and know where they go. Also please review tools needed list and make sure you have the tools needed to install the kit.

⚠WARNING Generally, braking performance and capability are decreased when larger/heavier tires and wheels are used. Take this into consideration while driving. Do not add, alter, or fabricate any factory or after-market parts to increase vehicle height over the intended height of the Rough Country product purchased. Mixing component brands is not recommended. Seat belts and shoulder harnesses should be worn at all times. Avoid situations where a side rollover may occur.

Rough Country makes no claims regarding lifting devices and excludes any and all implied claims. We will not be responsible for any product that is altered. We will be happy to answer any questions concerning the design, function, and use of our products.

⚠NOTICE The 4ö suspension system was developed using a 35 X 12.5 tire with aftermarket wheels. 20ö wheels with 5 1/2ö backspace or an 18ö wheel with 5ö of backspace will be required to maintain adequate clearance. The 6ö kit was developed using 37ö tires with aftermarket wheels. 20ö wheels with 5 1/2ö backspace or an 18ö wheel with 5ö of backspace will be required to maintain adequate clearance.
Stock wheels can be used with this lift with the addition of a 1/4ö wheel spacer. As with any tire and wheel combination it is recommended to trial fit the tire / wheel to assure there are no clearance problems.

⚠NOTICE Please note, this lift kit is not recommended for AWD (All Wheel Drive) Models.

⚠NOTICE DEALER AND VEHICLE OWNER

Any vehicle equipped with any Rough Country product should have a ñWarning to Driverö decal installed on the inside of the windshield or on the vehicleôs dash. The decal should act as a constant reminder for whoever is operating the vehicle of its unique handling characteristics.

INSTALLING DEALER - it is your responsibility to install the warning decal and forward these installation instructions on

Tools Needed:

WD-40	16mm Socket / Wrench
Loc-Tite	18mm Socket / Wrench
Reciprocating Saw	19mm Socket / Wrench
Hammer	21mm Socket / Wrench
Dead Blow Hammer	22mm Socket / Wrench
T30 Torx head bit	24mm Socket / Wrench
5mm Allen Wrench	35mm Socket
8mm Socket / Wrench	1 1/16” Socket
10mm Socket / Wrench	
13mm Socket / Wrench	
14mm Socket / Wrench	
15mm Socket / Wrench	

Torque Specs:

Size	Grade 5	Grade 8
5/16”	15 ft/lbs	20 ft/lbs
3/8”	30 ft/lbs	35 ft/lbs
7/16”	45 ft/lbs	60 ft/lbs
1/2”	65 ft/lbs	90 ft/lbs
9/16”	95 ft/lbs	130 ft/lbs
5/8”	135 ft/lbs	175 ft/lbs
3/4”	185 ft/lbs	280 ft/lbs

Class 8.8	Class 10.9
6MM	5 ft/lbs	9 ft/lbs
8MM	18ft/lbs	23 ft/lbs
10MM	32ft/lbs	45ft/lbs
12MM	55ft/lbs	75ft/lbs
14MM	85ft/lbs	120ft/lbs
16MM	130ft/lbs	165ft/lbs
18MM	170ft/lbs	240ft/lbs

trailfortress.com/rough-country-4-inch-lift-kit-32630