# Rough Country 37340 Installation Instructions

5-Inch Lift Kit with M1 Monotube Shocks for 2014-2018 Ram 2500 4WD, Part 37340

Part number: 37340

trailfortress.com/rough-country-5-inch-lift-kit-37340

Scan for fitment, price and install help

921368200

1368BAG4

# 2014-16 2500 Dodge 5” Lift Kit

**Thank you for choosing Rough Country Suspension for your Off Road needs**.

Rough Country recommends a certified technician installs this system. In addition to these instructions, professional knowledge of disassemble/reassembly procedures as well as post installation checks must be known. Attempts to install this system without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle. Average professional install time for this kit is 4-6 hours.

Please read all the instructions before beginning the installation. Check the kit hardware against the kit contents list on the last page. Be sure you have all the needed parts and understand where they go.

## Product Use Information

**WARNING** As a general rule, the taller a vehicle is the easier it will roll. We strongly recommend, because of roll-over possibility, that the vehicle be equipped with a functional roll-bar and cage system. Seat belts and should harnesses should be worn at all times. Avoid situations where a side rollover may occur.

Also check the steering stabilizer. It is a good idea when adding larger than stock tires to go with a larger bore steering stabilizer or a dual unit for tires 35ò and above. Inspect the stabilizer and replace as necessary.

**WARNING** Braking performance and capability are decreased when significantly large/heavier tires and wheels are used. Take this into consideration while driving.

Do no add, alter, or fabricate any factory or after-market parts which increase vehicle height over the intended height of the Rough Country product purchased. Mixing component brands, lifts, and/or combining body lift with suspension lifts voids all warranties. Rough Country makes no claims regarding lifting devices and excludes any and all implied claims. We will not be responsible for any product that is altered.

**NOTICE** This suspension system was developed for 37x12.50 tire on an aftermarket 17òx 9òor 20òwheels with a minimum of 5òback spacer. When larger tires are installed, speedometer recalibration is necessary. Due to ride height inconsistencies from the factory you may need to slightly trim the front plastic valance for proper tire clearance.

**On vehicles equipped with a two piece driveshaft & carrier bearing as on the Mega Cab, there is the potential for take off vibration, depending on the severity this can be corrected with shimming down the carrier bearing. Carrier bearing drop kit Part # 1110 is available from Rough Country.**

**NOTICE**

## Notice to Dealer and Vehicle Owner

Any vehicle equipped with any Rough country product must have the ñWarning to Driverò decal installed on the sun visor or dash. The decal is to act as a constant reminder for whoever is operating the vehicle of its unique handling characteristics. **INSTALLING DEALER—It is your responsibility to install the warning decal and to forward these installation instructions to the vehicle owner for review and to be kept in the vehicle for its service life.**

## Tools and Supplies Needed to Install Kit

| | |
|---|---|
| 1. Torque Wrenches | 8. Pitman Arm Puller |
| 2. ½òDrive Ratchet and Sockets | 9. Hammers |
| 3. Assorted Combination Wrenches | 10. C-Clamps |
| 4. Heavy Duty Jack Stands | 11. Center Punch |
| 5. Hydraulic Floor Jacks | 12. 17/32òDrill Bit |
| 6. Channel Locks | 13. 9/16òDrill Bit |
| 7. Anti-Seize Compound | 14. 3/8òDrill Bit ( at least 6òlong) |