TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 50009 Installation Instructions

Forged Upper Control Arms for Ranger with Cast Steel Knuckles

Part number: 50009

trailfortress.com/forged-upper-control-arms-ranger-with-cast-steel-knuckles-rough-country-50009

Scan for fitment, price and install help

921500080A

FORD 2019 Ranger Upper Control Arm Install

Thank you for choosing Rough Country for all your vehicle needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.
If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning this product.
Check all fasteners for proper torque. Check to ensure for adequate clearance between all components.
Periodically check all hardware for tightness.

KIT CONTENTS:
Drivers Side Upper Control Arm x 1
Passengers Side Upper Control Arm x 1
Control Arm Spacer x 4

TOOLS NEEDED:
10mm Wrench
18mm Wrench
21mm Socket
19mm Socket
Wheel Chocks
Torque Wrench
Drill Motor
9/16 Drill
Hammer
Long Nose Plyers
Philips Screw Driver

HARDWARE INCLUDED:

Upper Ball Joint Nuts
6327BAG x 2



Torque Specs:

Size	Grade 5	Grade 8	Size	Class 8.8	Class 10.9
5/16”	15 ft/lbs	20ft/lbs	6MM	5ft/lbs	9ft/lbs
3/8”	30 ft/lbs	35ft/lbs	8MM	18ft/lbs	23ft/lbs
7/16”	45 ft/lbs	60ft/lbs	10MM	32ft/lbs	45ft/lbs
1/2”	65 ft/lbs	90ft/lbs	12MM	55ft/lbs	75ft/lbs
9/16”	95 ft/lbs	130ft/lbs	14MM	85ft/lbs	120ft/lbs
5/8”	135ft/lbs	175ft/lbs	16MM	130ft/lbs	165ft/lbs
3/4”	185ft/lbs	280ft/lbs	18MM	170ft/lbs	240ft/lbs