TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 50010 Installation Instructions

6-Inch Coilover Conversion Kit with Vertex 2.5 Coilovers

Part number: 50010

trailfortress.com/rough-country-6-inch-coilover-conversion-upgrade-kit-50010

Scan for fitment, price and install help



FORD 2005-22 F-250 Vertex Coilover Conversion

Thank you for choosing Rough Country for all your vehicle needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.
If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning this product.
Check all fasteners for proper torque. Check to ensure for adequate clearance between all components.
Periodically check all hardware for tightness.

KIT CONTENTS:
Upper Coil Over Mount x2
Lower Coil Over Mount x2
Brake Line Relocation Bracket x2
Driver Vertex x1
Passenger Vertex x1
Front Shocks x2

TOOLS NEEDED:
10mm Wrench or Socket
18mm Wrench or Socket
21mm Wrench or Socket
22mm Wrench or Socket
7/16 Wrench or Socket
9/16 Wrench or Socket
30mm Socket
Drill Motor
.406 Drill Bit
Reciprocating Saw
Sander
Color Match Frame Paint
Paint Pen
Jack Stands
Jack

HARDWARE INCLUDED:
3/8-16 x 1.25 Hex Head Bolt x8
3/8" Washer x8
3/8-16 Flange Lock x8
14mm-2.0 x 40mm x2
14mm Lock Washer x2
14mm Flat Washer x10
14mm-2.0 x 75mm x4
14mm-2 Nylock Nut x4
1/4-20 x 1 Hex Head Bolt x6
1/4-20 Nylock Nut x6
1/4" Flat Washer x6

Torque Specs:

Size	Grade 5	Grade 8	Size	Class 8.8	Class 10.9
5/16"	15 ft/lbs	20ft/lbs	6MM	5ft/lbs	9ft/lbs
3/8"	30 ft/lbs	35ft/lbs	8MM	18ft/lbs	23ft/lbs
7/16"	45 ft/lbs	60ft/lbs	10MM	32ft/lbs	45ft/lbs
1/2"	65 ft/lbs	90ft/lbs	12MM	55ft/lbs	75ft/lbs
9/16"	95 ft/lbs	130ft/lbs	14MM	85ft/lbs	120ft/lbs
5/8"	135ft/lbs	175ft/lbs	16MM	130ft/lbs	165ft/lbs
3/4"	185ft/lbs	280ft/lbs	18MM	170ft/lbs	240ft/lbs