TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 501123 Installation Instructions

N3 Loaded Strut Pair for 2018–2023 Subaru Crosstrek AWD

Part number: 501123

trailfortress.com/rough-country-loaded-strut-pair-501123

Scan for fitment, price and install help

921501123

ROUGH COUNTRY
SUSPENSION SYSTEMS®

2018 - UP CrossTrek Front Strut Install

Thank you for choosing Rough Country for all your vehicle needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.
If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning this product.
Check all fasteners for proper torque. Check to ensure for adequate clearance between all components.
Periodically check all hardware for tightness.

KIT CONTENTS:
Driver Side Front Strut x1
Pass Side Front Strut x1

TOOLS NEEDED:
Jack
Safety Stands
Wheel Chocks
Torque Wrench
Metric Wrenches/Sockets
12mm
14mm
17mm
19mm
21mm

HARDWARE INCLUDED:
10mm Nuts x6



Torque Specs:

Size	Grade 5	Grade 8	Size	Class 8.8	Class 10.9
5/16”	15 ft/lbs	20ft/lbs	6MM	5ft/lbs	9ft/lbs
3/8”	30 ft/lbs	35ft/lbs	8MM	18ft/lbs	23ft/lbs
7/16”	45 ft/lbs	60ft/lbs	10MM	32ft/lbs	45ft/lbs
1/2”	65 ft/lbs	90ft/lbs	12MM	55ft/lbs	75ft/lbs
9/16”	95 ft/lbs	130ft/lbs	14MM	85ft/lbs	120ft/lbs
5/8”	135ft/lbs	175ft/lbs	16MM	130ft/lbs	165ft/lbs
3/4”	185ft/lbs	280ft/lbs	18MM	170ft/lbs	240ft/lbs