# Rough Country 501147 Installation Instructions

N3 Loaded Lifted Strut Pair for 2022–2025 Ford Maverick 4WD/AWD

Part number: 501147

trailfortress.com/rough-country-loaded-strut-pair-501147

Scan for fitment, price and install help

921501147

# FORD 2021 Maverick 2” Strut Lift Kit

**Thank you for choosing Rough Country for all your vehicle needs.**

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.
If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning this product.
Check all fasteners for proper torque. Check to ensure for adequate clearance between all components.
Periodically check all hardware for tightness.

**KIT CONTENTS:**
**Driver Strut x1**
**Passenger Strut x1**

**TOOLS NEEDED:**
Flat Pry Tool
18MM Socket/Wrench
10MM Socket/Wrench
13MM Socket/Wrench
15MM Socket/Wrench
18MM Socket/Wrench
19MM Socket/Wrench
21MM Socket/Wrench

**HARDWARE INCLUDED:**
**8mm Strut Bolts x6**



**Torque Specs:**

| Size | Grade 5 | Grade 8 | Size | Class 8.8 | Class 10.9 |
|---|---|---|---|---|---|
| 5/16” | 15 ft/lbs | 20ft/lbs | 6MM | 5ft/lbs | 9ft/lbs |
| 3/8” | 30 ft/lbs | 35ft/lbs | 8MM | 18ft/lbs | 23ft/lbs |
| 7/16” | 45 ft/lbs | 60ft/lbs | 10MM | 32ft/lbs | 45ft/lbs |
| 1/2” | 65 ft/lbs | 90ft/lbs | 12MM | 55ft/lbs | 75ft/lbs |
| 9/16” | 95 ft/lbs | 130ft/lbs | 14MM | 85ft/lbs | 120ft/lbs |
| 5/8” | 135ft/lbs | 175ft/lbs | 16MM | 130ft/lbs | 165ft/lbs |
| 3/4” | 185ft/lbs | 280ft/lbs | 18MM | 170ft/lbs | 240ft/lbs |

trailfortress.com/rough-country-loaded-strut-pair-501147