TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 5100 Installation Instructions

Adjustable Forged Track Bar for F-250/F-350 Super Duty (2005–2016)

Part number: 5100

trailfortress.com/adjustable-forged-track-bar-f250-f350-super-duty-rough-country-5100

Scan for fitment, price and install help

92151000

ROUGH COUNTRY SUSPENSION SYSTEMS®

Ford 05-16 Super Duty Adj. Track Bar

Thank you for choosing Rough Country for your off road needs.

Please read all the instructions before beginning the installation.

PRODUCT USE INFORMATION

We will be happy to answer any questions regarding our products by calling us @ 800-222-7023. Rough Country will not be responsible for any product that is altered.

KIT CONTENTS

1-Adj. Forged Track Bar

TOOLS NEEDED

24mm Socket
24mm Wrench
30mm Socket
Torque Wrench



INSTALLATION INSTRUCTIONS

1. Remove the track bar from the frame using a 30mm socket. Save hardware for reuse. **See Photo 1.**
2. Using a 24mm remove the track bar from the axle end. Save hardware for reuse. **See Photo 2.**



