TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 51075 Installation Instructions

Front Bumper with 20 Inch LED Bar and Amber DRL Pods for Bronco

Part number: 51075

trailfortress.com/front-bumper-bronco-rough-country-51075

Scan for fitment, price and install help

ROUGH COUNTRY
SUSPENSION SYSTEMS®

21 and UP Bronco Modular Bumper

Thank you for choosing Rough Country for all of your accessory needs.

Rough Country recommends that a certified technician install this system. In addition to these instructions, professional knowledge of disassemble/reassembly procedures as well as post installation checks must be known. Attempts to install this system without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle. Please read all the instructions before beginning the installation.

Check the kit hardware against the ‘‘Kit Contents’’ list. If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning this product. Check all fasteners for proper torque. Check to ensure for adequate clearance between all components. **Periodically check all hardware for tightness.**

Be sure you have all the needed parts and understand where they go. Also, please review the “Tools Needed” list to be certain you have the necessary tools to complete the installation.



