Rough Country 51089 Installation Instructions

SRX2 Adjustable Aluminum Steps for 2019–2025 Ford Ranger

Part number: 51089

trailfortress.com/rough-country-srx2-adjustable-aluminum-steps-51089

Scan for fitment, price and install help

ROUGH COUNTRY
SUSPENSION SYSTEMS®

FORD 2019-22 Ranger Crew Cab Aluminum Step Extrusion Brackets

Thank you for choosing Rough Country for all your vehicle needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.
If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning this product.
Check all fasteners for proper torque. Check to ensure for adequate clearance between all components.
Periodically check all hardware for tightness.

Kit Contents:
Step Rails x2
Front End Caps x2
Rear End Caps x2
Front Brackets x2
Mid/Rear Brackets x4
Steps x4

Tools Needed:
5mm Allen Wrench
13mm Socket/Wrench
16mm Socket/Wrench

Hardware Included:
8mm x 25mm Bolts x36
8mm Oversized Washers x12
8mm Flange Lock Nuts x36
8mm Finish Nuts x12
8mm x 10mm Button Head x12
10mm x 25mm Bolts x12
10mm Flat Washers x12



Torque Specs:

Size	Grade 5	Grade 8	Size	Class 8.8	Class 10.9
5/16”	15 ft/lbs	20ft/lbs	6MM	5ft/lbs	9ft/lbs
3/8”	30 ft/lbs	35ft/lbs	8MM	18ft/lbs	23ft/lbs
7/16”	45 ft/lbs	60ft/lbs	10MM	32ft/lbs	45ft/lbs
1/2”	65 ft/lbs	90ft/lbs	12MM	55ft/lbs	75ft/lbs
9/16”	95 ft/lbs	130ft/lbs	14MM	85ft/lbs	120ft/lbs
5/8”	135ft/lbs	175ft/lbs	16MM	130ft/lbs	165ft/lbs
3/4”	185ft/lbs	280ft/lbs	18MM	170ft/lbs	240ft/lbs

RC ROUGH COUNTRY