Rough Country 51120 Installation Instructions

51120

Part number: 51120

trailfortress.com/rough-country-hood-struts-51120

Scan for fitment, price and install help

921511200

ROUGH COUNTRY
SUSPENSION SYSTEMS®

FORD 2022 Maverick Hood Assist

Thank you for choosing Rough Country for all your vehicle needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.
If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning this product.
Check all fasteners for proper torque. Check to ensure for adequate clearance between all components.
Periodically check all hardware for tightness.

Kit Contents:
Dr Hood Bracket x1
Pass Hood Bracket x1
Dr Body Bracket x1
Pass Body Bracket x1
Wash Bottle Relocation Bracket x1
Hood Assist Cylinders x2

Tools Needed:
10mm Socket/Wrench
12mm Socket/Wrench
13mm Socket/Wrench

Hardware Included:
6mm x 16mm Bolt x1
6mm Lock Nut x1
6mm Flat Washer x1
5/16” x 1” Ball Studs x4
5/16” Flange Nuts x4



Torque Specs:

Size	Grade 5	Grade 8	Size	Class 8.8	Class 10.9
5/16”	15 ft/lbs	20ft/lbs	6MM	5ft/lbs	9ft/lbs
3/8”	30 ft/lbs	35ft/lbs	8MM	18ft/lbs	23ft/lbs
7/16”	45 ft/lbs	60ft/lbs	10MM	32ft/lbs	45ft/lbs
1/2”	65 ft/lbs	90ft/lbs	12MM	55ft/lbs	75ft/lbs
9/16”	95 ft/lbs	130ft/lbs	14MM	85ft/lbs	120ft/lbs
5/8”	135ft/lbs	175ft/lbs	16MM	130ft/lbs	165ft/lbs
3/4”	185ft/lbs	280ft/lbs	18MM	170ft/lbs	240ft/lbs