Rough Country 585 Installation Instructions

2.5-Inch Lift Kit for 2003–2013 Ford Expedition 4WD/RWD

Part number: 585

trailfortress.com/rough-country-2-5-inch-lift-kit-585

Scan for fitment, price and install help



9258500REV1

03-11 Ford Expedition 2WD/4WD 2.5” lift

Thank you for choosing Rough Country for all your suspension needs.

Rough Country recommends a certified technician install this system. In addition to these instructions, professional knowledge of disassemble/reassembly procedures as well as post installation checks must be known. Attempts to install this system without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle.

Please read instructions before beginning installation. Check the kit hardware against the parts list. Be sure you have all needed parts and know where they go. Also please review tools needed list and make sure you have needed tools.

PRODUCT USE INFORMATION

As a general rule, the taller a vehicle is, the easier it will roll. Seat belts and shoulder harnesses should be worn at all times. Avoid situations where a side rollover may occur.

Generally, braking performance and capability are decreased when larger/heavier tires and wheels are used. Take this into consideration while driving. Do not add, alter, or fabricate any factory or after-market parts to increase vehicle height over the intended height of the Rough Country product purchased. Mixing component brands is not recommended.

Rough Country makes no claims regarding lifting devices and excludes any and all implied claims. We will not be responsible for any product that is altered.

If question exist we will be happy to answer any questions concerning the design, function, and correct use of our products. Please call us at 800-222-7023 with any questions you may have.

This suspension system was developed using a 305/65/17 tire on a 17” factory wheels. The kit is designed to level your Expedition raising the front of approximately 2.5” and the rear 1”. If you desire a different configuration please contact your nearest Rough Country distributor.

NOTICE TO DEALER AND VEHICLE OWNER

Any vehicle equipped with any Rough Country product should have a “Warning to Driver” decal installed on the inside of the windshield or on the vehicle’s dash. The decal should act as a constant reminder for whoever is operating the vehicle of its unique handling characteristics.

INSTALLING DEALER - it is your responsibility to install the warning decal and forward these installation instructions on to the vehicle owner for review. These instructions should be kept in the vehicle for its service

Kit Contents:
2-Front Strut Extensions
2-1/4” Thick rear Strut Spacers
4-3/8” Thick rear Coil Spacers
1-Kit Bag
6-3/8x2” Bolts
6-3/8” Flange Lock Nuts

Tools Needed:
15mm Wrench
15mm Socket
29mm Socket
1 1/16” Wrench
21mm Wrench
16 mm Wrench
21 mm Wrench
3/8” mm Wrench
Hammer
9/16” wrench



Torque Specs:

Size	Grade 5	Grade 8
3/8”	30 ft/lbs	35 ft/lbs
7/16”	45 ft/lbs	60 ft/lbs
1/2”	65 ft/lbs	90 ft/lbs
9/16”	95 ft/lbs	130 ft/lbs
5/8”	135 ft/lbs	175 ft/lbs
3/4”	185 ft/lbs	280 ft/lbs

	Class 8.8	Class 10.9
12MM	55ft/lbs	75ft/lbs
14MM	85ft/lbs	120ft/lbs
16MM	130ft/lbs	165ft/lbs
18MM	170ft/lbs	240ft/lbs

ROUGH COUNTRY SUSPENSION SYSTEMS