Rough Country 675-76-8130 Installation Instructions

4-Inch Lift Kit with N3 Shocks for Jeep CJ5/CJ7 4WD (1976-1981)

Part number: 675-76-8130

trailfortress.com/rough-country-4-inch-lift-kit-675-76-8130

Scan for fitment, price and install help



76-86 Jeep CJ 4” Lift System

Thank you for choosing Rough Country for all your suspension needs.

Rough Country recommends a certified technician install this system. In addition to these instructions, professional knowledge of disassemble/reassembly procedures as well as post installation checks must be known. Attempts to install this system without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle.

Please read instructions before beginning installation. Check the kit hardware against the parts list on this page. Be sure you have all needed parts and know where they go. Also please review tools needed list and make sure you have needed tools.

PRODUCT USE INFORMATION

As a general rule, the taller a vehicle is, the easier it will roll. Seat belts and shoulder harnesses should be worn at all times. Avoid situations where a side rollover may occur.

Generally, braking performance and capability are decreased when larger/heavier tires and wheels are used. Take this into consideration while driving. Do not add, alter, or fabricate any factory or after-market parts to increase vehicle height over the intended height of the Rough Country product purchased. Mixing component brands is not recommended.

Rough Country makes no claims regarding lifting devices and excludes any and all implied claims. We will not be responsible for any product that is altered.

If question exist we will be happy to answer any questions concerning the design, function, and correct use of our products.

This suspension system was developed using a 33x12.50x15, tire with factory wheels. **Note** if wider tires are used, offset wheels will be required and trimming will be required.

NOTICE TO DEALER AND VEHICLE OWNER

Any vehicle equipped with any Rough Country product should have a “Warning to Driver” decal installed on the inside of the windshield or on the vehicle’s dash. The decal should act as a constant reminder for whoever is operating the vehicle of its unique handling characteristics.

INSTALLING DEALER - it is your responsibility to install the warning decal and forward these installation instructions on to the vehicle owner for review. These instructions should be kept in the vehicle for its service

Kit Contents

2– 8019 Front Springs
2– 8020 Rear Springs
1-6606 Power Steering Pitman Arm
1675 Kit Box containing
7-1/2”x2 3/4”x6 1/4” U-bolts
1-1/2” x 3 1/4” x 6 3/4” U-bolts
1 1/2” Bag
2– 3/8” x 4” Center Pins
1-1675Bag1 Spring Bushing Bag
1– 1675Bag2 Sway Bar Bag
1– 1675Bag3 Transfer Spacer Case Bag
2– Sway Bar Links
8114/9114 Shocks

Torque Specs

Size	Grade 5	Grade 8
5/16”	15 ft/lbs	20 ft/lbs
3/8”	30 ft/lbs	35 ft/lbs
7/16”	45 ft/lbs	60 ft/lbs
1/2”	65 ft/lbs	90 ft/lbs
9/16”	95 ft/lbs	130 ft/lbs
5/8”	135 ft/lbs	175 ft/lbs
3/4”	185 ft/lbs	280 ft/lbs