TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 67800 Installation Instructions

2-Inch Leveling Kit for Jeep Grand Cherokee & Cherokee

Part number: 67800

trailfortress.com/2-inch-leveling-kit-jeep-grand-cherokee-cherokee-rough-country-67800

Scan for fitment, price and install help

ROUGH COUNTRY
SUSPENSION SYSTEMS®

11-18 JEEP WK2 2” LEVELING KIT

Rough Country recommends a certified technician install this system. In addition to these instructions, professional knowledge of disassemble/reassembly procedures as well as post installation checks must be known. Attempts to install this system without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle.

Please read instructions before beginning installation. Check the kit hardware against the parts list on this page. Be sure you have all needed parts and know where they go. Also please review tools needed list and make sure you have needed tools.

PRODUCT USE INFORMATION

As a general rule, the taller a vehicle is, the easier it will roll. Seat belts and shoulder harnesses should be worn at all times. Avoid situations where a side rollover may occur.

Generally, braking performance and capability are decreased when larger/heavier tires and wheels are used. Take this into consideration while driving. Do not add, alter, or fabricate any factory or after-market parts to increase vehicle height over the intended height of the Rough Country product purchased. Mixing component brands is not recommended.

Rough Country makes no claims regarding lifting devices and excludes any and all implied claims. We will not be responsible for any product that is altered.

If questions exist we will be happy to answer any questions concerning the design, function, and correct use of our products.

This suspension system was developed using a 265/70 R17 tire with factory wheels. **Note** if wider tires are used, offset wheels will be required and trimming will be required.

⚠NOTICE This kit will not work on vehicles with air suspension.

⚠NOTICE NOTICE TO DEALER AND VEHICLE OWNER

Any vehicle equipped with any Rough Country product should have a “Warning to Driver” decal installed on the inside of the windshield or on the vehicle’s dash. The decal should act as a constant reminder for whoever is operating the vehicle of its unique handling characteristics.

INSTALLING DEALER - it is your responsibility to install the warning decal and forward these installation instructions on to the vehicle owner for review. These instructions should be kept in the vehicle for its service

Kit Contents:

67800 Kit Box
2– Front Strut Spacers
1-67800BAG1
6-8MM Nylock Nuts



Tools Needed:
8mm Socket
8mm Allen
10mm Socket
13mm Socket
13mm Wrench
19mm Wrench
21mm Socket
21mm Wrench
22mm Deep Well Socket
24mm Wrench
32mm Socket
Jack
Jack Stands
Hand Grinder
Torque Wrench
Hammer