TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 69620 Installation Instructions

6.5-Inch Lift Kit with N3 Shocks for 1984-2001 Jeep Cherokee XJ

Part number: 69620

trailfortress.com/rough-country-6-5-inch-lift-kit-69620

Scan for fitment, price and install help

92169600

ROUGH COUNTRY
SUSPENSION SYSTEMS®

84-01 6.5” XJ CHEROKEE LIFT KIT

Thank you for choosing Rough Country for your suspension needs.

Rough Country recommends a certified technician installs this system. In addition to these instructions, professional knowledge of disassemble/reassembly procedures as well as post installation checks must be known. Attempts to install this system without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle.

Please read all the instructions before beginning the installation. Check the kit hardware against the parts list. Be sure you have all the needed parts and understand where they go. Also please review the tools needed and make sure you are confident about undertaking this installation. If you have any questions about the installation of this kit, call Rough Country at 800-222-7023.

PRODUCT USE INFORMATION

⚠WARNING As a general rule, the taller a vehicle is the easier it will roll. We strongly recommend, because of roll-over possibility, that the vehicle be equipped with a functional roll-bar and cage system. Seat belts and shoulder harnesses should be worn at all times. Avoid situations where a side rollover may occur.

Braking performance and capabilities are decreased when significantly larger/heaver tires and wheels are used. Take this into consideration while driving. Also, speedometer recalibration is necessary when larger tires are installed.

Do not add, alter, or fabricate any factory or after-market parts which increase vehicle height over the intended height of the Rough Country product purchased. Mixing component brands, lifts, voids all warranties. Rough Country makes no claims regarding lifting devices and excludes any and all implied claims. We will not be responsible for any product that is altered.

This kit features Rough Country’s adjustable joint design. Adjustable end tool is included in kit. Assemble the joints per the separate instruction sheet Part # 92RCJ120 provided

The 6.5ò suspension system was developed for 33x11.50x15 tire on 15 x 8 after market wheel with 3.75ò of back spacing. This tire size may require the installation of aftermarket flares and due to variation in vehicles when manufactured and the numerous options available, the amount of actual lift gained by this lift kit will vary. On models outfitted with extra bolt-on equipment and accessories, Rough Country offers new coil spring isolator pads made from polyurethane to boost ride height 3/4".

⚠NOTICE NOTICE TO DEALER AND VECHICLE OWNER

Any vehicle equipped with any Rough country product must have the ñWarning to Driverò decal installed on the sun visor or dash. The decal is to act as a constant reminder for whoever is operating the vehicle of its unique handling characteristics. **INSTALLING DEALER**ð It is your responsibility to install the warning decal and to forward these installation instructions on too the vehicle owner for review and to be kept in the vehicle for its service life.

TOOLS NEEDED:

Spring Compressor	**Allen Wrenches**
Pitman Arm Puller	**Torx Key Socket**
Silicone Spray	**Tape Measure**
½” Drill	**File**
Drill Assortment (1/8” to 1/2")	**Large “C” Clamps and/or Bench Vise**
Torque Wrench	**Hydraulic Floor Jacks**
Hammer	**Heavy Duty Jack Stands**
½” Drive Ratchet and Sockets	**Wheel Chocks (Wooden Blocks)**
Combination Wrenches	**Grease or Anti Seize Compound**

If question exist we will be happy to answer any questions concerning the design, function, and correct use of our products. Please call us at 800-222-7023. The required installation time for this kit is 6-8 hours.