Rough Country 699013 Installation Instructions

Vertex 2.5 Adjustable Rear Shocks for 2007-2021 Toyota Tundra

Part number: 699013

trailfortress.com/rough-country-vertex-2-5-adjustable-rear-shocks-699013

Scan for fitment, price and install help

TOYOTA 2007-19 Tundra Rear Vertex Shocks

Thank you for choosing Rough Country for all your vehicle needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.
If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning this product.
Check all fasteners for proper torque. Check to ensure for adequate clearance between all components.
Periodically check all hardware for tightness.



Tools Needed:
18mm Socket/Wrench

Kit Contents:
Driver Rear Vertex Shocks x1
Pass Rear Vertex Shocks x1

Torque Specs:

Size	Grade 5	Grade 8	Size	Class 8.8	Class 10.9
5/16”	15 ft/lbs	20ft/lbs	6MM	5ft/lbs	9ft/lbs
3/8”	30 ft/lbs	35ft/lbs	8MM	18ft/lbs	23ft/lbs
7/16”	45 ft/lbs	60ft/lbs	10MM	32ft/lbs	45ft/lbs
1/2”	65 ft/lbs	90ft/lbs	12MM	55ft/lbs	75ft/lbs
9/16”	95 ft/lbs	130ft/lbs	14MM	85ft/lbs	120ft/lbs
5/8”	135ft/lbs	175ft/lbs	16MM	130ft/lbs	165ft/lbs
3/4”	185ft/lbs	280ft/lbs	18MM	170ft/lbs	240ft/lbs

INSTALLATION INSTRUCTONS

1. Install the rear Vertex shocks in the stock location using the supplied hardware in the upper mount on the stem and the stock hardware in the lower mount. Use a 18mm wrench. **See Photo 1.**

