TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 70569 Installation Instructions

Hidden Bumper LED Light Bar Mounts for Ram 2500/3500 4WD (2011-2018)

Part number: 70569

trailfortress.com/rough-country-led-bumper-mount-70569

Scan for fitment, price and install help

927056900

2010-15 Dodge 2500/3500 40” Curved LED Light Mount

Thank you for choosing Rough Country for all your off road needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.
If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning the design, function, and correct use of our products.

Tools Needed:
18mm Socket



Kit Contents:
2-Rough Country LED Light Brackets

INSTALLATION INSTRUCTIONS

1. Using an 18mm socket remove the four factory bolts securing each tow hook to the frame. Retain for reuse.
2. Place the Rough Country bracket in place of the tow hook, with the light mounting tab to the outside, using factory hardware. Tighten using an 18mm socket. **See Photo 1.**
3. Install the 40òlight bar between the brackets and secure to brackets with the supplied bolt. **See Photo 2.**
4. Wire the light with the supplied light instruction sheet.





Thank You for choosing Rough Country for your lighting needs!!!

By purchasing any item sold by Rough Country, LLC, the buyer expressly warrants that he/she is in compliance with all applicable Federal, State, and Local laws and regulations regarding the purchase, ownership, and use of the item. It shall be the buyers responsibility to comply with all Federal, State and Local laws governing the sales of any items listed, illustrated or sold. The buyer expressly agrees to indemnify and hold harmless Rough Country, LLC for all claims resulting directly or indirectly from the purchase, ownership, or use of the items.