TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 70776 Installation Instructions

20-Inch Chrome Series LED Light Bar Kit for Jeep Grand Cherokee

Part number: 70776

trailfortress.com/rough-country-led-light-kit-70776

Scan for fitment, price and install help

ROUGH COUNTRY
SUSPENSION SYSTEMS®

JEEP 2011-17 WK2 Grand Cherokee 20” LED LIGHT BRACKETS

Thank you for choosing Rough Country for all your off road lighting needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.
This bracket kit was designed to fit a Led curved light 20” long from mounting surface to mounting surface.

KIT CONTENTS
Driver Bracket (1)
Passenger Bracket (1)
10mm x 35mm Bolts (4)
10mm Flat Washers (4)
10mm Lock Washers (4)



TOOLS NEEDED
10mm Socket
13mm Socket
Flat Screwdriver/Pushpin Tool
Ratchet
Torque Wrench
30mm Wrench (Factory Tow Hooks)

INSTALLATION INSTRUCTIONS

1. Using a flat screwdriver or removal tool, remove the pushpin from behind the air dam. Retain for reuse. **See Photo 1.**
2. Using a 10mm socket, remove the 5 bolts holding the front skid plate on. Remove the skid plate and retain the hardware for reuse. **See Photo 2.**





3. Remove the 7 twist clips. Retain for reuse. There will be 2 in each wheel well and 3 across the front. **See Photo 3.**
4. Pull on the front of the bumper to remove. **See Photo 4.**



