TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 70964 Installation Instructions

MLC-6 Multiple Light Controller for Jeep Wrangler 4WD (2018-2025)

Part number: 70964

trailfortress.com/rough-country-mlc6-multiple-light-controller-70964

Scan for fitment, price and install help

921709640

ROUGH COUNTRY SUSPENSION SYSTEMS®

JEEP JL MLC-6 KIT

Thank you for choosing Rough Country for all your lighting needs.

NOTICE Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.
If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning the design, function, and correct use of our products.

NOTE: This kit is intended to be used on JL vehicles **not** equipped with the factory auxiliary switches.

Tools Needed:
Phillips Screwdriver
5.5 Socket
7MM Socket
Ratchet
Plastic Pry Tool

Kit Contents
Switch face w/ Wiring Harness
Relay Pod w/ Power & Ground Wires Zip Ties
Under hood mounting bracket



1. Park the vehicle on a smooth level surface.
2. Using a 13mm socket, remove the two bolts closest to washer tank as shown in **Photo 1 & 2**. Retain the hardware for re-use**.**





3. Position the fuse panel as shown in **Photo 3** and secure with the factory hardware. Tighten using a 13mm wrench.
4. Locate the factory plastic cap in the fire wall on the drivers side about half way down the fire wall and remove it by turning it. It will need to be drilled to allow the wiring harness to pass through it. **See Photo 4.**





5. Drill the cap using a step bit or comparable bit to 3/4” to allow the supplied grommet to be installed. See Photo 5. **(Note: Grommet is already installed on the wiring harness)**
6. Install the power and ground leads to the fuse panel and tighten using a 10mm wrench. Do not over tighten the nut. **See Photo 6.**





7. Remove the control bezel by prying with a plastic pry tool on the passenger side. Take care not to damage surrounding area or clips. **See Photo 7.**
8. Using a 7mm socket, remove the bolt as shown securing the lower window control bezel. **See Photo 8.**





9. Unplug all connectors to the bezel.
10. Remove the 7 bolts using a 5.5mm socket. **See Photo 9 & 10.** Retain 4 of the factory screws for re-use.





11. Install the new switch bezel in the factory bezel as shown in **Photo 11** and secure with the 4 factory screws**.**
12. Reinstall the assembled switch bezel in the dash using the factory hardware. Tighten using a 7mm socket. **See Photo 12.**





13. Reinstall the factory switch bezel removed in Step 2 making sure to properly align the tabs and popping the bezel back into place.

⚠ NOTICE AFTER INSTALLATION, YOU MUST START THE ENGINE TO ACTIVATE THE SYSTEM! ⚠ NOTICE

By purchasing any item sold by Rough Country, LLC, the buyer expressly warrants that he/she is in compliance with all applicable , State, and Local laws and regulations regarding the purchase, ownership, and use of the item. It shall be the buyers responsibility to comply with all Federal, State and Local laws governing the sales of any items listed, illustrated or sold. The buyer expressly agrees to indemnify and hold harmless Rough Country, LLC for all claims resulting directly or indirectly from the purchase, ownership, or use of the items.