TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 73220 Installation Instructions

Tailgate Assist (Rough Country 73220)

Part number: 73220

trailfortress.com/tailgate-assist-rough-country-73220

Scan for fitment, price and install help

ROUGH COUNTRY SUSPENSION SYSTEMS®

921732140

FORD 2004-14 F150/SUPERDUTY TAILGATE ASSIST

Thank you for choosing Rough Country for all your vehicle needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.
If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning this product.
Check all fasteners for proper torque. Check to ensure for adequate clearance between all components.
Periodically check all hardware for tightness.

KIT CONTENTS:
1 - Tailgate Assist Piston
1 - Tailgate Cable Bracket
2 - Spacer (Super Duty Kits Only)

Hardware Included:
1 - Riv-nut
1 - Threaded ball Insert
1 - 5/16" Large Washer (F150 Kits Only)

Tools Required:
T-50 Torx
17/32 Drill
Drill Motor
13mm Wrench
Nut Insert Tool (optional)



Torque Specs:

Size	Grade 5	Grade 8	Size	Class 8.8	Class 10.9
5/16"	15 ft/lbs	20ft/lbs	6MM	5ft/lbs	9ft/lbs
3/8"	30 ft/lbs	35ft/lbs	8MM	18ft/lbs	23ft/lbs
7/16"	45 ft/lbs	60ft/lbs	10MM	32ft/lbs	45ft/lbs
1/2"	65 ft/lbs	90ft/lbs	12MM	55ft/lbs	75ft/lbs
9/16"	95 ft/lbs	130ft/lbs	14MM	85ft/lbs	120ft/lbs
5/8"	135ft/lbs	175ft/lbs	16MM	130ft/lbs	165ft/lbs
3/4"	185ft/lbs	280ft/lbs	18MM	170ft/lbs	240ft/lbs