TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 74130 Installation Instructions

6-Inch Lift Kit with N3 Shocks for 1995-2004 Toyota Tacoma, Part 74130

Part number: 74130

trailfortress.com/rough-country-6-inch-lift-kit-74130

Scan for fitment, price and install help

ROUGH COUNTRY SUSPENSION SYSTEMS®

1741BAG5

TOYOTA 1995.5-04 TACOMA 2WD/4WD 6” Kit

Thank you for choosing Rough Country for your suspension needs.

Rough Country recommends a certified technician install this system. In addition to these instructions, professional knowledge of disassembly/reassembly procedures as well as post installation checks must be known. Attempts to install this system without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle.

Please read instructions before beginning installation. Check the kit hardware against the parts list on this page and the product layout on the last page. Be sure you have all needed parts and know where they go. Also please review tools needed list and make sure you have needed tools.

PRODUCT USE INFORMATION

⚠WARNING As a general rule, the taller a vehicle is, the easier it will roll. Seat belts and shoulder harnesses should be worn at all times. Avoid situations where a side rollover may occur.

Generally, braking performance and capability are decreased when larger/heavier tires and wheels are used. Take this into consideration while driving. Do not add, alter, or fabricate any factory or after-market parts to increase vehicle height over the intended height of the Rough Country product purchased. Mixing component brands is not recommended.

Rough Country makes no claims regarding lifting devices and excludes any and all implied claims. We will not be responsible for any product that is altered.

This suspension system was developed using a maximum tire size of 305/70-R17 or 34” tall x 12” wide, on a 17x9 wheel with 5” backspacing/0mm offset.

NOTICE DEALER AND VEHICLE OWNER

Any vehicle equipped with any Rough Country product should have a “Warning to Driver” decal installed on the inside of the windshield or on the vehicle’s dash. The decal should act as a constant reminder for whoever is operating the vehicle of its unique handling characteristics.

INSTALLING DEALER - it is your responsibility to install the warning decal and forward these installation instructions on to the vehicle owner for review. These instructions should be kept in the vehicle for its service

Tools Needed:

10mm Socket/Wrench
12mm Socket/Wrench
12mm Allen
13mm Socket/Wrench
14mm Socket/Wrench
15mm Wrench
16mm Wrench
17mm Socket/Wrench
18mm Wrench
19mm Socket/Wrench
21mm Socket/Wrench
22mm Socket/Wrenches
36mm Socket (Auto Hubs)
Hammer
Chisel (Manual Hubs)
Snap Ring Pliers (Manual Hubs)
Drain Pan
3/8” Allen
1/2” Socket/Wrench
9/16” Socket/Wrench
13/16” Socket
1-1/16” Socket/Wrench
1-1/8” Wrench
13/32” Drill
Drill Motor
Reciprocating Saw
File
Die Grinder w/ Cutoff Wheel
Torque Wrench
Jack
Jack Stands

Torque Specs:

Size	Grade 5	Grade 8
5/16”	15 ft/lbs	20 ft/lbs
3/8”	30 ft/lbs	35 ft/lbs
7/16”	45 ft/lbs	60 ft/lbs
1/2”	65 ft/lbs	90 ft/lbs
9/16”	95 ft/lbs	130 ft/lbs
5/8”	135 ft/lbs	175 ft/lbs
3/4”	185 ft/lbs	280 ft/lbs

	Class 8.8	Class 10.9
6MM	5 ft/lbs	9 ft/lbs
8MM	18ft/lbs	23 ft/lbs
10MM	32ft/lbs	45ft/lbs
12MM	55ft/lbs	75ft/lbs
14MM	85ft/lbs	120ft/lbs
16MM	130ft/lbs	165ft/lbs

trailfortress.com/rough-country-6-inch-lift-kit-74130