TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 743 Installation Instructions

2-Inch Leveling Kit with Strut Extensions for Toyota Tacoma

Part number: 743

trailfortress.com/2-inch-leveling-kit-toyota-tacoma-rough-country-743

Scan for fitment, price and install help

921743000

2005-20 TACOMA 2” Molded Leveling Kit

Thank you for choosing Rough Country for all your suspension needs.

Rough Country recommends a certified technician install this system. In addition to these instructions, professional knowledge of disassemble/reassembly procedures as well as post installation checks must be known. Attempts to install this system without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle.

Please read instructions before beginning installation. Check the kit hardware against the parts list on the last page. Be sure you have all needed parts and know where they go. Also please review tools needed list and make sure you have needed tools.

PRODUCT USE INFORMATION

⚠WARNING As a general rule, the taller a vehicle is, the easier it will roll. We strongly recommend, because of rollover possibility, that the vehicle be equipped with a functional roll-bar and cage system. Seat belts and shoulder harnesses should be worn at all times. Avoid situations where a side rollover may occur.

Generally, braking performance and capability are decreased when larger/heavier tires and wheels are used. Take this into consideration while driving. Do not add, alter, or fabricate any factory or after-market parts to increase vehicle height over the intended height of the Rough Country product purchased. Mixing component brands is not recommended.

Rough Country makes no claims regarding lifting devices and excludes any and all implied claims. We will not be responsible for any product that is altered.

If question exist we will be happy to answer any questions concerning the design, function, and correct use of our products.

This lift was designed as a leveling kit. It provides 2” of lift to the front of the vehicle. The recommended tire size when using this kit is a 265/75R 17 on stock wheels. If wider tires are desired or wheels with something other than factory offset please consult a tire and wheel expert to confirm fitment.

⚠NOTICE NOTICE TO DEALER AND VEHICLE OWNER

Any vehicle equipped with any Rough Country product should have a “Warning to Driver” decal installed on the inside of the windshield or on the vehicle’s dash. The decal should act as a constant reminder for whoever is operating the vehicle of its unique handling characteristics.

INSTALLING DEALER - it is your responsibility to install the warning decal and forward these installation instructions on to the vehicle owner for review. These instructions should be kept in the vehicle for its service

Kit Contents:

Front Strut Extensions x2
10mm-1.5 x 40mm x6
10mm Washer x6
10mm-1.5 Nuts x6

Tools Needed:

12mm Wrench
14mm Socket
17mm Socket
17mm Wrench
19mm Socket
19mm Wrench
16mm Wrench
21mm Socket
Hammer
Needle Nose Pliers
Sander

Torque Specs

Size	Grade 5	Grade 8
5/16”	15 ft/lbs	20 ft/lbs
3/8”	30 ft/lbs	35 ft/lbs
7/16”	45 ft/lbs	60 ft/lbs
1/2”	65 ft/lbs	90 ft/lbs
9/16”	95 ft/lbs	130 ft/lbs
5/8”	135 ft/lbs	175 ft/lbs
3/4”	185 ft/lbs	280 ft/lbs

MM	8.8	10.9	12.9
10MM	32ft/lbs	45ft/lbs	50ft/lbs

trailfortress.com/2-inch-leveling-kit-toyota-tacoma-rough-country-743