Rough Country 761 Installation Instructions

3-Inch Lift Kit for 2003–2009 Toyota 4Runner 4WD (X-REAS), Part 761

Part number: 761

trailfortress.com/rough-country-3-inch-lift-kit-761

Scan for fitment, price and install help

92176100

03-09 4 Runner 3” Front 2” Rear Leveling Kit

Thank you for choosing Rough Country for your suspension needs.

Rough Country recommends a certified technician install this system. In addition to these instructions, professional knowledge of disassembly/reassembly procedures as well as post installation checks must be known. Attempts to install this system without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle.

Please read instructions before beginning installation. Check the kit hardware against the parts list on this page and the product layout on the last page. Be sure you have all needed parts and know where they go. Also please review tools needed list and make sure you have needed tools.

⚠NOTICE Will fit X-REAS suspension models.

PRODUCT USE INFORMATION

⚠WARNING As a general rule, the taller a vehicle is, the easier it will roll. Seat belts and shoulder harnesses should be worn at all times. Avoid situations where a side rollover may occur.

Generally, braking performance and capability are decreased when larger/heavier tires and wheels are used. Take this into consideration while driving. Do not add, alter, or fabricate any factory or after-market parts to increase vehicle height over the intended height of the Rough Country product purchased. Mixing component brands is not recommended.

Rough Country makes no claims regarding lifting devices and excludes any and all implied claims. We will not be responsible for any product that is altered.

If questions exist we will be happy to answer any questions concerning the design, function, and correct use of our products.

This suspension system was developed using a Maximum tire size of 285/70R-17 tire with factory wheels. For aftermarket wheel and tire combinations consult your tire and wheel specialist.

⚠NOTICE NOTICE TO DEALER AND VEHICLE OWNER

Any vehicle equipped with any Rough Country product should have a ñWarning to Driverò decal installed on the inside of the windshield or on the vehicleôs dash. The decal should act as a constant reminder for whoever is operating the vehicle of its unique handling characteristics.

INSTALLING DEALER - it is your responsibility to install the warning decal and forward these installation instructions on to the vehicle owner for review. These instructions should be kept in the vehicle for its service

Kit Contents:

2-Front Strut Spacers
2-Rear Coil Springs
2-Rear Shock Relocation Brackets
1-Shock Relocation Hardware Bag Includes:
- 2ï 3/4-10x 3.5ò Bolts
- 2ï 3/4-10 Nylock Nuts
- 4ï 3/4 Flat Washers
- 2ï 3/8-16 x 1.25 Bolts
- 2ï 3/8-16 Flange Lock Nuts
- 2ï Flag Washers



Tools Needed:

12 mm Wrench
14 mm Socket
17 mm Socket
17 mm Wrench
19 mm Socket
Hammer
16mm Wrench
21mm Socket
9/16ò wrench