Rough Country 8597 Installation Instructions

2-Inch FK/FF-Code Leveling Kit for Silverado/Sierra 2500 HD

Part number: 8597

trailfortress.com/2-inch-fk-ff-code-leveling-kit-silverado-sierra-2500-hd-rough-country-8597

Scan for fitment, price and install help

92859500

ROUGH COUNTRY SUSPENSION SYSTEMS®

02-10 HD TORSION ADJUSTERS W/SHOCK BRACKETS

Thank you for choosing Rough Country for your suspension needs.

Rough Country recommends a certified technician install this system. In addition to these instructions, professional knowledge of disassemble/reassembly procedures as well as post installation checks must be known. Attempts to install this system without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle.

PRODUCT USE INFORMATION

⚠WARNING As a general rule, the taller a vehicle is, the easier it will roll. Offset, as much as possible, what is lost in rollover resistance by increasing tire track width. In other words, go "wide" as you go "tall".

Do not add, alter, or fabricate any factory or after-market parts to increase vehicle height over the intended height of the Rough Country product purchased. Mixing component brands, lifts, and/or combining body lift with suspension lifts voids all warranties. Rough Country makes no claims regarding lifting devices and excludes any and all implied claims. We will not be responsible for any product that is altered.

Braking performance and capability are decreased when significantly larger/heavier tires and wheels are used. Take this into consideration while driving.

The required installation time for this system is approximately 2 hours. This suspension system was developed using 285x75R16 tire on an 8" wheel. Before installing other combinations, please consult your local tire and wheel specialist.

⚠NOTICE A front-end alignment should ALWAYS be checked after installing ANY vehicle suspension lift. This kit typically requires a slight toe-in adjustment. Record the ride height measurement at the time of alignment. If, in the future the torsion bars settle excessively, alignment can be restored by adjusting-up the bars to their original ride height.

⚠NOTICE **NOTICE TO DEALER AND VEHICLE OWNER**

Any vehicle equipped with any Rough Country product should have a "Warning to Driver" decal installed on the inside of the windshield or on the vehicle's dash. The decal should act as a constant reminder for whoever is operating the vehicle of its unique handling characteristics.

RECOMMENDED TOOLS

• Floor jack • Heavy duty jack stands • Safety glasses	• Wheel chocks • Ball Joint Remover like **OTC7249**	• Impact gun • 18 mm socket • 15 mm socket • 21 mm socket



By purchasing any item sold by Rough Country, LLC, the buyer expressly warrants that he/she is in compliance with all applicable , State, and Local laws and regulations regarding the purchase, ownership, and use of the item. It shall be the buyers responsibility to comply with all Federal, State and Local laws governing the sales of any items listed, illustrated or sold. The buyer expressly agrees to indemnify and hold harmless Rough Country, LLC for all claims resulting directly or indirectly from the purchase, ownership, or use of the items.