Rough Country 8730130 Installation Instructions

N3 Steering Stabilizer (Rough Country 8730130)

Part number: 8730130

trailfortress.com/rough-country-n3-steering-stabilizer-8730130

Scan for fitment, price and install help

9218730100

ROUGH COUNTRY SUSPENSION SYSTEMS®

GM 2016-22 2500 Steering Stabilizer Kit

Thank you for choosing Rough Country for all your vehicle needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.
If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning this product.
Check all fasteners for proper torque. Check to ensure for adequate clearance between all components.
Periodically check all hardware for tightness.

Kit Contents:

1 - 81134 Bolt and Taper Sleeve
- 1 - 1/2” x 3 1/2” Bolt
- 1 - 1/2” Lock Washer
- 1 - 1/2” Hex Nut
- 1 - 1/2” Flat Washer
- 2 - 1/2” Thick Washers
- 1 - Tapered Sleeve
- 1 - 1/2” ID Sleeve

1 - Instruction Sheet
1 - N3 or V2 Shock Pair

1 - 87311Bag
- 1 - 12mm x 65mm Bolt
- 1 - 12mm Flange Lock Nut
- 1 - Sleeve

1 - 87301Bag
- 1 - 12mm x 120mm Bolt
- 2 - 12mm Flat Washers
- 1 - 12mm Lock Nut
- 2 - 18mm Flat Washers
- 1 - 3.8” Long Sleeve

Tools Needed:

18mm Socket/Wrench
19mm Socket/Wrench
27mm Socket/Wrench



Torque Specs:

Size	Grade 5	Grade 8	Size	Class 8.8	Class 10.9
5/16”	15 ft/lbs	20ft/lbs	6MM	5ft/lbs	9ft/lbs
3/8”	30 ft/lbs	35ft/lbs	8MM	18ft/lbs	23ft/lbs
7/16”	45 ft/lbs	60ft/lbs	10MM	32ft/lbs	45ft/lbs
1/2”	65 ft/lbs	90ft/lbs	12MM	55ft/lbs	75ft/lbs
9/16”	95 ft/lbs	130ft/lbs	14MM	85ft/lbs	120ft/lbs
5/8”	135ft/lbs	175ft/lbs	16MM	130ft/lbs	165ft/lbs
3/4”	185ft/lbs	280ft/lbs	18MM	170ft/lbs	240ft/lbs