Rough Country 8732330 Installation Instructions

N3 Steering Stabilizer for Dodge Ram 1500/2500/3500 4WD (1994–2012)

Part number: 8732330

trailfortress.com/rough-country-n3-steering-stabilizer-8732330

Scan for fitment, price and install help

INSTALLATION INSTRUCTIONS **FORM NO. 82253**

1. When you remove original equipment steering stabilizer, retain factory nut and bolt for reuse.

2. **Kit includes two separate tapered sleeves**.
   94-97 Dodge 1500, use fasteners and tapered sleeve from the 87323bag1.
   98-99 Dodge 1500, reuse stock fasteners, and sleeves from kit bag. Does not require tapered sleeve.
   00-02 Dodge 1500, use fasteners from 87323bag1, but use tapered sleeve from separate kit bag
3. Assemble piston rod of cylinder and pin kit with 87323bag1, if needed.

4. Extend stabilizer, from tie rod mount to frame mount, place sleeve into bushing, and install using factory bolt and nut.

IMPORTANT NOTES:

5. Tighten nuts securely on both ends of steering stabilizer.

6. Turn wheels fully to right and left making sure that no interference occurs and that wheel stops are fully contacted.

BOX CONTENT

1 ï Stabilizer Cylinder
1 ï Installation Instruction Sheet
1 ï Pin Assembly Kit
2 ï Sleeve

CAUTION: Any and all warranties including but not limited to any express warranties, implied warranty of merchantability, or implied warranty of fitness for a particular purpose shall not apply to any product altered in any way outside the premises of the manufacturer or to any product which is not installed in accordance with the written instructions provided by the manufacturer for installation of the product.

trailfortress.com/rough-country-n3-steering-stabilizer-8732330