Rough Country 8734830 Installation Instructions

N3 Steering Stabilizer for 1997–2003 Ford F-150 RWD

Part number: 8734830

trailfortress.com/rough-country-n3-steering-stabilizer-8734830

Scan for fitment, price and install help

INSTALLATION INSTRUCTIONS **FORM NO. 82170**



Note: All surfaces should be clean and dry before attaching bracket.

1. Place wheels in straight forward position.
2. Place stabilizer bracket “A” inside of frame rail as shown. Place back-up strap on the outside of frame. Install bolts through back-up strap and through bracket “A”. Secure with lock washers and nuts provided.
3. Attach stabilizer to bracket “A” using bushing assembly instructions printed on bag.
4. Loosely attach stabilizer bracket “B” to the tie rod as shown using u-bolt and flange lock nuts.
5. Attach stabilizer to bracket “B” as shown, using bushing assembly instructions printed on bag.
6. Extend stabilizer piston 4 ½”. Rotate bracket “B” to obtain best location. Tighten all nuts securely on u-bolts.
7. Turn wheels fully to the right and left, making sure that no interference occurs and that wheel stops are fully contacted.
8. Re-check all nuts and pal nuts for tightness before releasing installation.

Box content

One stabilizer cylinder
One mounting strap
One mounting bracket (frame)
One mounting bracket (tie rod)
One installation instruction sheet

Poly bag

4 - rubber bushings
4 - cup washers
2 - lock washers 3/8
2 - hex nuts 3/8
2 - pal nuts 3/8
2 - hex head bolts 5”
4 - flange lock nuts 5/16”
2 - u-bolts 1 1/8”

Caution: Any and all warranties including but not limited to any express warranties, implied warranty of merchantability, or implied warranty of fitness for a particular purpose shall not apply to any product altered in any way outside the premises of the manufacturer or to any product which is not installed in accordance with the written instructions provided by the manufacturer for installation of the product.

trailfortress.com/rough-country-n3-steering-stabilizer-8734830

INSTRUCCIONES DE INSTALACIÓN **FORMA NO. 82170**



NOTA: TODOS LOS LUGARES DEBEN DE ESTAR LIMPIOS Y SECOS ANTES DE CONECTAR ABRAZADERAS.

1. Para comensar ponga las ruedas en posición derecha al frente.
2. Ponga la abrazadera "A" del estabilizador, adentro del riel de la estructura (como se mira) ponga la correa de refuerso afuera de la estructura, y instale los tornillos atraves de la correa de refuerso y atraves de la abrazadera "A". Asegurelos con las rondanas de candado y las tuercas que se proveen.
3. Conecte el estabilizador a la abrazadera “A” viendo las instrucciones que vienen en la bolsa.
4. Conecte la abrazadera “B” del estabilizador a la varilla de connexion, usando los tornillos en froma de “U” y sus tuercas planas de candado.
5. Conecte el estabilizador a la abrazadera “B” viendo las instrucciones que vienen en la bolsa.
6. Estire la varilla del piston 4 1/2 pulgadas y despues gire y alinie la abrazadera para obtener mejor locacion y apriete todos los tornillos en forma de “U”.
7. Mueva las ruedas **todo** a la izquierda y a la derecha para que no haya ninguna interferencia y estar seguro que los altos de las ruedas hagan buen contacto.
8. Revise todos los tornillos y tuercas para que esten bien apretados, antes de entregarse la nueva instalacion.

CAJA DE CONTENIDO

1 – cilindro estabilizador
1 – correa de refuerso de montage
1 – abrazadera de montaje (estructura)
1 – abrazadera de montaje (varilla)
1- hoja de instrucciones para instalar

BOLSA DE CONTENIDO

4 – empaques de hule
4 – rondanas de tasa
2 – rondanas de candado 3/8
2 – tuercas especiales hex duras 3/8
2 – tuercas dobles 3/8
2 – tornillos de cabeza hexagonal 5”
4 – tuercas planas de candado 5/16”
2 – tornillos en forma de “U” 1 1/8”

PRECAUCION: Cualquiera y todas las garantías que se incluyen pero no limitada a cualquier garantía escrita, la garantía implícita de mercancia, o la garantía implícita de aptitud para un propósito particular no aplicará a cualquier producto alterado de forma alguna fuera de las promesas del fabricante o a cualquier producto que no se instala de acuerdo con las instrucciones escritas hecho por el fabricante de la instalación del producto.

trailfortress.com/rough-country-n3-steering-stabilizer-8734830