Rough Country 8734830 Installation Instructions

N3 Steering Stabilizer for 1997–2003 Ford F-150 RWD

Part number: 8734830

trailfortress.com/rough-country-n3-steering-stabilizer-8734830

Scan for fitment, price and install help

INSTALLATION INSTRUCTIONS **FORM NO. 82170**



Note: All surfaces should be clean and dry before attaching bracket.

1. Place wheels in straight forward position.
2. Place stabilizer bracket “A” inside of frame rail as shown. Place back-up strap on the outside of frame. Install bolts through back-up strap and through bracket “A”. Secure with lock washers and nuts provided.
3. Attach stabilizer to bracket “A” using bushing assembly instructions printed on bag.
4. Loosely attach stabilizer bracket “B” to the tie rod as shown using u-bolt and flange lock nuts.
5. Attach stabilizer to bracket “B” as shown, using bushing assembly instructions printed on bag.
6. Extend stabilizer piston 4 ½”. Rotate bracket “B” to obtain best location. Tighten all nuts securely on u-bolts.
7. Turn wheels fully to the right and left, making sure that no interference occurs and that wheel stops are fully contacted.
8. Re-check all nuts and pal nuts for tightness before releasing installation.

Box content

One stabilizer cylinder
One mounting strap
One mounting bracket (frame)
One mounting bracket (tie rod)
One installation instruction sheet

Poly bag

4 - rubber bushings
4 - cup washers
2 - lock washers 3/8
2 - hex nuts 3/8
2 - pal nuts 3/8
2 - hex head bolts 5”
4 - flange lock nuts 5/16”
2 - u-bolts 1 1/8”

Caution: Any and all warranties including but not limited to any express warranties, implied warranty of merchantability, or implied warranty of fitness for a particular purpose shall not apply to any product altered in any way outside the premises of the manufacturer or to any product which is not installed in accordance with the written instructions provided by the manufacturer for installation of the product.

trailfortress.com/rough-country-n3-steering-stabilizer-8734830