Rough Country 88000_B Installation Instructions

1.75-Inch Leveling Kit for Toyota Sequoia (2023-2025)

Part number: 88000_B

trailfortress.com/1-75-inch-leveling-kit-toyota-sequoia-rough-country-88000-b

Scan for fitment, price and install help

92188000

ROUGH COUNTRY SUSPENSION SYSTEMS®

TOYOTA 2007-23 TUNDRA / 2022-23 SEQUOIA 1.75” LEVELING KIT

Thank you for choosing Rough Country for your suspension needs.

Rough Country recommends a certified technician install this system. In addition to these instructions, professional knowledge of disassembly/reassembly procedures as well as post installation checks must be known. Attempts to install this system without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle.

Please read instructions before beginning installation. Check the kit hardware against the parts list on this page and the product layout on the last page. Be sure you have all needed parts and know where they go. Also please review tools needed list and make sure you have needed tools.

PRODUCT USE INFORMATION

⚠WARNING As a general rule, the taller a vehicle is, the easier it will roll. Seat belts and shoulder harnesses should be worn at all times. Avoid situations where a side rollover may occur. Generally, braking performance and capability are decreased when larger/heavier tires and wheels are used. Take this into consideration while driving. Do not add, alter, or fabricate any factory or after-market parts to increase vehicle height over the intended height of the Rough Country product purchased. Mixing component brands is not recommended.

Rough Country makes no claims regarding lifting devices and excludes any and all implied claims. We will not be responsible for any product that is altered. If questions exist about the design, function, installation, and correct use of our products please call one of our customer service representatives at 800-222-7023.

This suspension system was developed using a Maximum tire size of 285/65 -18 tire with factory wheels. For aftermarket wheel and tire combinations consult your tire and wheel specialist.

⚠NOTICE NOTICE TO DEALER AND VEHICLE OWNER

Any vehicle equipped with any Rough Country product should have a “Warning to Driver” decal installed on the inside of the windshield or on the vehicle’s dash. The decal should act as a constant reminder for whoever is operating the vehicle of its unique handling characteristics.

INSTALLING DEALER - it is your responsibility to install the warning decal and forward these installation instructions on to the vehicle owner for review. These instructions should be kept in the vehicle for its service life.

KIT CONTENT:

2-Front Strut Spacers

1-88000BAG1 Kit Bag that includes:
- 8-10mm x 50mm Bolts
- 8-10mm Flange Lock Nuts

TOOLS NEEDED:

Hammer
9/16” Wrench
13/16” Wrench
10mm Wrench/Socket
12mm Wrench/Socket
14mm Wrench/Socket
17mm Wrench/Socket
19mm Wrench/Socket
22mm Wrench
Torque Wrench
Thread Locker
Jack

TORQUE SPECS

Size	Grade 5	Grade 8
Standard		
3/8”	30 ft/lbs	35 ft/lbs
9/16”	95 ft/lbs	130 ft/lbs
Metric		
8mm	25ft/lbs	
10mm	42 ft/lbs.	
12mm	70 ft/lbs.	
14mm	95 ft/lbs.	
16mm	200ft./lbs	
18mm	475ft./lbs	