Rough Country 90005_A Installation Instructions

Speedometer Calibrator for Chevy/GMC 2500HD/3500HD Diesel (2017-2019)

Part number: 90005_A

trailfortress.com/rough-country-speedometer-calibrator-90005-a

Scan for fitment, price and install help

929000500

ROUGH COUNTRY SUSPENSION SYSTEMS®

Inline Speedometer Calibration Kit

Thank you for choosing Rough Country.

NOTICE Please read instructions before beginning installation. Be sure you have read and understand the procedures and the unit has been configured and updated prior installing.

If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning function, and correct use of our products.

This installation manual shows an example installation on a 2017 Chevrolet 1500. The installation may vary for your vehicle, so it may be necessary to consult a Chevrolet service manual for specific instructions for your year model.

Be advised: These instructions may not include specifics for all vehicle configurations.

INSTALLATION INSTRUCTIONS

1. Connect the Inline Speedometer Module to your PC with the supplied USB cable and configure it to your vehicle. Once configuration is complete, connect the module to the harness.





2. There is a small module with 2 connectors, underneath the dash on the left side, above the emergency brake pedal. This will be in front of a larger module with several connectors. We will be removing the black connector. With a pick or small screwdriver, slide the red locking clip backwards and depress the tab on top while pulling back to remove the connector.
3. Plug the male end of the Speedometer Calibrator harness into the factory harness, making sure to align the retaining clips so that they are both facing up. Insert a zip tie through the retaining clips for security. Be sure not to pull it too tight to avoid damage to the clips.



