TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 90005 Installation Instructions

Speedometer Calibrator for Chevrolet & GMC Trucks (2017-2019)

Part number: 90005

trailfortress.com/rough-country-speedometer-calibrator-90005

Scan for fitment, price and install help

929000501

ROUGH COUNTRY SUSPENSION SYSTEMS®

Inline Speedometer Calibration Kit

Thank you for choosing Rough Country.

NOTICE Please read instructions before beginning installation. Be sure you have read and understand the procedures and the unit has been configured and updated prior installing.
If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning function, and correct use of our products.

This installation manual shows an example installation on a 2017 Chevrolet Colorado. The installation may vary for your vehicle, so it may be necessary to consult a Chevrolet service manual for specific instructions for your year model.
Be advised: These instructions may not include specifics for all vehicle configurations.

INSTALLATION INSTRUCTIONS

1. Connect the Inline Speedometer Module to your PC with the supplied USB cable and configure it to your vehicle. Once configuration is complete, connect the module to the harness.





2. To remove the Lower Kick Panel, first remove the (2) 7mm screws at the bottom
3. Pull back on the Left and Right side of the Kick Panel at the top to release it. There is one connector for the headlight switch on the left.
   NOTE The hood release may come loose from the panel, if so, wait until the panel is re-attached to install it. It clips in place starting at the front.



