TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 90016 Installation Instructions

Speedometer Calibrator for Ford F-250/F-350 4WD (2011-2016)

Part number: 90016

trailfortress.com/rough-country-speedometer-calibrator-90016

Scan for fitment, price and install help

929001600

ROUGH COUNTRY SUSPENSION SYSTEMS®

Inline Speedometer Calibration Kit

Thank you for choosing Rough Country.

NOTICE Please read instructions before beginning installation. Be sure you have read and understand the procedures and the unit has been configured and updated prior installing.
If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning function, and correct use of our products.

This installation manual shows an example installation on a 2011 F-250 Super Duty. The installation may vary for your vehicle, so it may be necessary to consult a Ford service manual for specific instructions for your year model.
Be advised: These instructions may not include specifics for all vehicle configurations.

INSTALLATION INSTRUCTIONS

1. Connect the Inline Speedometer Module to your PC with the supplied USB cable and configure it to your vehicle. Once configuration is complete, connect the module to the harness.





2. Set parking brake! Do not skip this step!
3. Carefully, with a trim removal tool or screwdriver, remove the Power Port panel .
4. Using a 7mm socket, remove the (1) retaining screw



