Rough Country 90300 Installation Instructions

2-Inch Lift Kit for 2018–2025 Subaru Crosstrek AWD

Part number: 90300

trailfortress.com/rough-country-2-inch-lift-kit-90300

Scan for fitment, price and install help

ROUGH COUNTRY SUSPENSION SYSTEMS®

90300BAG2

2018 - UP CrossTrek 2” Lift Kit

Thank you for choosing Rough Country for all of your suspension needs.

Rough Country recommends that a certified technician install this system. In addition to these instructions, professional knowledge of disassemble/reassembly procedures as well as post installation checks must be known. Attempts to install this system without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle. Please read all the instructions before beginning the installation. Check the kit hardware against the ‘’Kit Contents’’ list below. If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning this product. Check all fasteners for proper torque. Check to ensure for adequate clearance between all components. Check and retighten wheels at 50 miles and again at 500 miles. Periodically check all hardware for tightness. Be sure you have all the needed parts and understand where they go. Also, please review the “Tools Needed” list to be certain you have the necessary tools to complete the installation.

PRODUCT USE INFORMATION

⚠WARNING As a general rule, the taller a vehicle is the easier it will roll. We strongly recommend that seat belts and shoulder harnesses be worn at all times. Braking performance and capabilities are decreased when significantly larger/heavier tires and wheels are used. Do not add, alter, or fabricate any factory or after-market parts which increase vehicle height over the intended height of the Rough Country product purchased. Rough Country makes no claims regarding lifting devices and excludes any and all implied claims. We will not be responsible for any product that is altered.

TIRE FITMENT

This kit was developed using a 215/75/r15 for a no rub on a 15x8 +15 offset while 235/75/r15 will fit with minor trimming / moving of plastic wheel liners and removing factory “mud flaps”. Due to differences in manufacturing, dimension and inflated measurements, tire and wheel combinations should be test fit prior to installation.

NOTICE TO DEALER AND VEHICLE OWNER

⚠NOTICE Any vehicle equipped with any Rough country product must have the “Warning to Driver” decal installed on the sun visor or dash. The decal is to act as a constant reminder for whoever is operating the vehicle of its unique handling characteristics. INSTALLING DEALER—It is your responsibility to install the warning decal and to forward these installation instructions on too the vehicle owner for review and to be kept in the vehicle for its service life.

trailfortress.com/rough-country-2-inch-lift-kit-90300