TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 92061 Installation Instructions

Winch Mount with 4500-Lb Winch for Honda Talon 1000

Part number: 92061

trailfortress.com/winch-mount-honda-talon-1000-rough-country-92061

Scan for fitment, price and install help



HONDA 2020 Talon Winch Mount

Thank you for choosing Rough Country for all your vehicle needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.
If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning this product.
Check all fasteners for proper torque. Check to ensure for adequate clearance between all components.
Periodically check all hardware for tightness.

KIT CONTENTS:
Winch Plate x1
Winch Plate Shim x1
Winch Plate Clamp Driver x1
Winch Plate Clamp Passenger x1
Fairlead Mount x1
Fairlead Square Washers x2

TOOLS NEEDED:
5mm Allen Wrench
13mm Wrench or Socket
14mm Wrench or Socket
18mm Wrench or Socket
19mm Wrench or Socket

HARDWARE INCLUDED:
12mm-1.75 x 90mm Hex Head Bolts x2
12mm-1.75 x 65mm Hex Head Bolts x2
12mm Flat Washer x4
12mm-1.75 Flange Lock Nut x4
10mm-1.5 x 35mm Hex Head Bolts x4
10mm Flat Washers x8
10mm-1.5 Nylock Nut x4



Torque Specs:

Size	Grade 5	Grade 8	Size	Class 8.8	Class 10.9
5/16”	15 ft/lbs	20ft/lbs	6MM	5ft/lbs	9ft/lbs
3/8”	30 ft/lbs	35ft/lbs	8MM	18ft/lbs	23ft/lbs
7/16”	45 ft/lbs	60ft/lbs	10MM	32ft/lbs	45ft/lbs
1/2”	65 ft/lbs	90ft/lbs	12MM	55ft/lbs	75ft/lbs
9/16”	95 ft/lbs	130ft/lbs	14MM	85ft/lbs	120ft/lbs
5/8”	135ft/lbs	175ft/lbs	16MM	130ft/lbs	165ft/lbs
3/4”	185ft/lbs	280ft/lbs	18MM	170ft/lbs	240ft/lbs

INSTALLATION INSTRUCTONS

1. Insert the (4) square nuts into the bottom mounts of the winch. **See Photo 1.**
2. Install the winch plate onto the winch and secure using (4) of the supplied 8mm-1.25 x 25mm Hex Head Bolts, (4) 8mm Flat Washers and (4) 8mm Lock Washers. **See Photo 2.**





3. Use a 13mm socket to tighten the bolts in the winch plate. **See Photo 3.**
4. Using a 5mm allen wrench remove the (2) bolts in the side of the front bumper of the UTV. **See Photo 4.** Retain Hardware for later use.





5. Remove the (3) bolts in the side of the bumper using a 13mm socket. Repeat this process on the opposite side and remove the bumper. **See Photos 5.**
6. Using a jack lift up the UTV and support the UTV by placing jack stands under the frame. Using an 18mm socket, remove the front upper control arm bolt on each side. **See Photo 6.**
7. Remove the front upper control arm bolt on each side. Then install (1) of the supplied 12mm-1.75 x 90mm Hex Head Bolts and (1) 12mm Flat Washer into the upper mount and control arm. Do not install the nut at this time.





8. Install the winch and plate into the front of the UTV. Place the plate onto the (2) upper control arm bolts. Then secure with the (2) supplied 12mm-1.75 Flange lock nuts. **See Photo 7.**
9. Install the lower shim in-between the winch plate and the chassis of the UTV. **See Photo 8.**





10. Locate the winch plate clamps. **Dr side has 1 notch and the pass side has 2. See Photo 9.**
11. Install the winch plate clamp around the chassis of the UTV to the winch plate and shim. Then secure the clamp using (2) of the supplied 10mm-1.5 x 35mm Hex Head Bolts (4) 10mm Flat Washers and (2) 10mm-1.5 Nylock Nuts. **See Photo 10.**





12. Install the opposite side winch plate clamp using the same process as in step 11. **See Photo 11.**
13. Tighten the winch plate clamps using a 17mm wrench and socket. Then tighten the upper control arm mount bolts using a 18mm socket and a 19mm wrench. **See Photo 12.**





14. Place the fairlead mount onto the front bumper measuring 1” from the back of the bumper tube. Center mark the hole on each side to be drilled through the top and bottom of the bumper. **See Photo 13.**
15. Use a 27/64” drill bit to drill through the top and bottom of the bumper mount on each side. **See Photo 14.**





16. Install the bumper onto the UTV using the retained hardware on each side. **See Photo 15.**
17. Install the fairlead onto the mount using (2) of the supplied 8mm-1.25 x 25mm Hex Head Bolts, (2) 8mm Lock Washers and (2) 8mm-1.25 Nut. Tighten using a 13mm socket for the bolt and a 14mm wrench for the nut. **See Photo 16.**





18. Install the fairlead onto the bumper using (2) of the supplied 12mm-1.75 x 65mm Hex Head Bolts and (2) 12mm Flat Washers, (2) thick square washers on the bottom of the bumper and secure using (2) 12mm-1.75 Flange Lock Nuts. **See Photo 17.**
19. Install the winch rope into the fairlead, install the hook using the supplied hardware. **See Photo 18.**





20. Connect the winch control module wiring to the winch. Then mount the winch control module and secure any loose wiring away from moving parts.
21. Lift the UTV up and remove the jack stands, then lower onto the ground.


HONDA
TALON
HONDA

By purchasing any item sold by Rough Country, LLC, the buyer expressly warrants that he/she is in compliance with all applicable, State, and Local laws and regulations regarding the purchase, ownership, and use of the item. It shall be the buyers responsibility to comply with all Federal, State and Local laws governing the sales of any items listed, illustrated or sold. The buyer expressly agrees to indemnify and hold harmless Rough Country, LLC for all claims resulting directly or indirectly from the purchase, ownership, or use of the items.