TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country RC714 Installation Instructions

1.25-Inch Body Lift Kit for 2014–2015 Silverado & Sierra 1500

Part number: RC714

trailfortress.com/1-25-inch-body-lift-kit-silverado-sierra-1500-rough-country-rc714

Scan for fitment, price and install help



2014 GM 4WD 1500 P/U 1 1/4” Body Lift

Thank you for choosing Rough Country for all your suspension needs.

Rough Country recommends a certified technician install this kit. Attempts to install this kit without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle. Please read instructions before beginning installation. Check the kit hardware against the kit contents list page. Be sure you have all needed parts and know where they go. Review tools needed list and make sure you have the tools needed to install the kit.

PRODUCT USE INFORMATION

We will not be responsible for any product that is altered. We will be happy to answer any questions concerning the design, function, and use of our products by calling 800-222-7023.

Kit was designed for use with both standard cab and 4 door models. Standard cabs will not utilize all cab mount spacers. Standard cabs only will use the cab strap extension brackets.
This body lift was developed using a 33x12.5x20 tire with factory wheels. Combo kits are available. Ask your Rough Country Dealer for more info.

NOTICE TO DEALER AND VEHICLE OWNER

Any vehicle equipped with any Rough Country product should have a ñWarning to Driverò decal installed on the inside of the windshield or on the vehicleôs dash. The decal should act as a constant reminder of the vehicles unique handling characteristics. These instructions should be kept in the vehicle for its service life.

Kit Contents:

1-Fr Bumper Driver Relocation Bracket
1-Fr Bumper Passenger Relocation Bracket
1-E-brake Bracket
1-Rear Bumper Shim
1-Rr Bumper Driver Relocation Bracket
1-Rr Bumper Passenger Relocation Bracket
6-1 1/4” 2014 GM Cab Spacers
2-1 1/4” X 3” Body Pucks
10-1 1/4” X 2” Body Pucks
2-Standard Cab Strap Ext.

RC714BAG2 Containing:
- **12—3/8” x 2.25” Bolt**
- **12—3/8” Washers**
- **12—3/8” Nylocks**
- **1—1/2” x 1” Bolt**
- **3—1/2” Washers**
- **1—1/2” Nylock**
- **2—10mm x 30mm Button Head Bolts**
- **2—3/8” USS Washers**
- **4—12mm Flange Lock**
- **2—12mm x 35mm Bolt**

RC714BAG3 Containing:
- **8—12mm x 65mm Bolts**
- **8—1/2” Washers**
- **2—14mm x 140mm Bolts**

Tools Needed:

Jack	**8mm Socket**
Jack Stands	**10mm Socket / Wrench**
Wood Blocks (2x4)	**11mm Socket / Wrench**
Pliers	**12mm Socket / Wrench**
Hammer	**13mm Socket / Wrench**
Phillips Screwdriver	**14mm Socket / Wrench**
Drill Motor	**15mm Socket / Wrench**
1/2” Drill Bit	**16mm Socket / Wrench**
Reciprocating Saw	**18mm Socket / Wrench**
	19mm Socket / Wrench
	21mm Socket / Wrench
	22mm Socket / Wrench
	Hand Grinder
	#15, #40, & #45 Torx bit

FRONT INSTALLATION INSTRUCTIONS

1. Disconnect battery using a10mm socket
2. Using a screwdriver disconnect the air filter inlet hose from air box. **See Photo 1.** Lock the steering wheel and mark upper and lower steering shaft. Remove steering shaft from rack and pinion using a 11mm socket.
3. Remove the ten plastic clips from the radiator bezel using a screwdriver. **See Photo 2.**





4. Remove the painted bumper bezel from truck using a 7mm socket, remove the two bolts on both side. **See Photo 3.**
5. Unclip the painted bumper bezel from the grill. There are six clips behind the bumper. Pull the sides of bumper bezel out then pull back to remove. **See Photo 4.** This may take two people .





6. Remove the 8 bolts holding the front grill on using a 10mm socket. There are 4 bolts on top **See Photo 5** and 4 bolts on bottom **See Photo 6** of the grill. There are two clips on each side. Pull straight out to release clips





7. Remove the side bumper support bracket using a 15mm socket . **See Photo 7.**
8. Unplug the fog lights and wiring harness from bumper. **See Photo 8.**





9. Use a 18mm socket to remove the four bolts holding the bumper on to the frame then remove bumper. **See Photo 9.**
10. Remove front bumper brackets using a 15mm socket. **See Photo 10.**





11. Then remove tow hooks using a 18mm socket and wrench. **See Photo 11.**
12. Using a 10mm socket remove the ground wires from frame. Two of the ground wires are on both front body mounts. **See Photo 12.**





13. The other ground wire is on passenger side body mount behind the tire. **See Photo 13.**
14. Remove the O2 sensor wire clip from frame just above passenger side body mount. On driver side remove the wiring loom bracket using a 13mm socket. **See Photo 14.** Remove the wire clips from the top of strut bolts.





15. Measure the emergency brake cable adjustment bolt from back of nut to the end of threads and record this measurement for later use. (Should be about 2.5ò). **See Photo 15.**
16. Then adjust bolt to allow slack so the brake cable can be disconnected. Then release the metal clips holding the emergency cable to frame on body mount. **See Photo 16.**





17. Loosen the front body mount bolts using a 18mm socket and a 21mm on the other body mount bolts. **See Photo 17.** Remove the nuts from the body bushing using a 15mm socket. **See Photo 18.** Only remove the bolt on one side at a time. Lift the body off of frame just enough to remove body bushing. Look an make sure no other wires or brake lines are being stretched. Front body mount bolt must come out from the top.





18. Once the bushing is out knock the two studs out using a hammer and vise. **See Photo 19.** Replace the two stud with the supplied 3/8òx 2.25òbolts, washers, and nuts. Install cab body puck on body bushing and place on truck. **See Photo 20**.





19. Install the 1.25òx 3òround body puck onto of rear cab body bushing. Use a 14mm socket and wrench to tighten new bolt. Lower body onto body bushing and install body bolts but do not tighten at this time. Install a new rear cab bolt 14mm x 140mm. **See Photo 21.** Repeat step for other side. **Make sure the wiring does not get pinch under the flag bolt on the two front body mounts while installing.** Once all body puck are in tighten all bolts using 19mm for front body bolts 21mm for middle bolts and 22mm for rear cab bolts.
20. Install emergency brake line bracket using the supplied 1/2òx 1òbolt, washer, and nut. Use a 19mm socket and wrench to tighten. **See Photo 22.** Reconnect the emergency brake cable. Take a 1/4 off inch off the original measurement taken adjust the parking brake cable to around 2.25òfrom the back of the nut to the end of the threads.





21. Reinstall ground wires and O2 sensor clip back onto frame using 10mm socket. Ground wire on passenger side body mount be hide tire will need a clip removed to get slack in wire.

22. On the front frame horns measure the tow hook mounting hole on the side with only one hole 1 1/2òback and 1 3/16ò up from bottom of frame. **See Photo 23.** Mark the area and drill a new hole for the tow hooks using a 1/2 drill. Flip the tow hooks and install bolts. Tighten using 18mm socket. **See Photo 24.**


PHOTO 23


PHOTO 24

23. Install new front bumper brackets using stock hardware, push up on the bracket when you tighten the bolts. Using the bracket for a template mark and remove the lower inside of frame horn and out side corners. Use a sawzall or cut off wheel to remove the material. **See Photo 25, 26, and 27.**
24. After cutting reinstall the bumper bracket with factory bolts and the supplied 10mm x 30mm button head bolt and washer for the outside hole. Pull up on the bracket and tighten bracket using a 15mm socket and a 6mm allen wrench. **See Photo 28.**


PHOTO 25


PHOTO 26


PHOTO 27


PHOTO 28

25. On the inside of the front bumper where the tow hooks holes are measure 1/4 down on the inner bumper bracket and cut even with the sides of the holes. **See Photo 29.**
26. Install front bumper using stock hardware with the supplied 12mm nuts. Use a 18mm socket and wrench to tighten bumper bolts. **See Photo 30.**





27. Reinstall front grill using stock hardware and a 10mm socket to tighten all 8 bolts. Reinstall painted bumper bezel using stock hardware. Reinstall steering shaft using a 15mm. Reconnect air inlet hose to air box. Reinstall radiator bezel using the stock plastic clips.
28. Tighten the side bumper support bracket using a 15mm socket. Push the bracket up while tightening the bolts

BED/REAR BUMPER INSTALLATION INSTRUCTIONS

****Note** The bumper is removed in the first three pictures to help show locations for the bolts and electrical plugs. The bumper is not removed until step 3.**

1. Loosen the 8 bolts holding the bed on using a 18mm socket. **See Photo 1.** Remove the six rear bolts on bed leaving the front bolts near cab in but loose. Lift the rear of bed up just enough to place one of the body puck between frame and bed. This is done so rear bumper can be removed. **See Photo 2.**





2. Unplug the rear bumper wiring from the junction box on the frame and unplug the 7 way connector from bumper. **See Photo 3.**
3. With the license plate remove reach be hide the bumper and remove the two bolts using a 13mm wrench. One is on the left and one on the right. Using a 15mm, 18mm and a 21mm socket remove bumper bolts. **See Photo 4.** (note bumper was remove to show better picture). Remove bumper and place on a clean surface.





4. Mark and cut the tap off the frame for the spare tire tube. Cut straight across the top making the top flat with no ridge. **See Photo 5.**



5. Using a torx 15 to remove lower bumper screws from the plastic bumper cover. **See Photo 6.**
6. Using a 7mm socket remove the screws from the inside of bumper. **See Photo 7.**





7. Using a screwdriver remove the metal clips from the plastic bumper cover. There will be five metal clips to be removed. **See Photo 8.**
8. Using a pair of pliers to release the plastic clips holding the bumper cover to metal part of the bumper, while pulling on the bumper cover to separate. Only remove enough to allow removal of bumper mounting bracket. **See Photo 9.**





9. Using a 45 torx remove the five bolts holding the bumper mounting bracket. **See Photo 10.**
10. Remove the threaded body clip from the stock bumper brackets and place clips in the same area on the new supplied bumper brackets. **See Photo 11.**





11. Install new bumper brackets using stock hardware and a 40 torx to tighten. **See Photo 12.**
12. Reassemble rear bumper
13. Remove the body puck from the rear of bed that was place to help remove the bumper and install the bed bolts on one side of the truck to hold the bed in place while installing bed pucks. Hand tighten bolts. Remove the bolt from front of bed that was left loose earlier.
14. Lift one side of the bed at a time and install the five 1 1/4 body pucks. **See Photo 13.** Use the supplied 12mm bolts, washers. Repeat this step for other side. Use a 19mm socket to tighten bed bolts


PHOTO 12


PHOTO 13

15. Install rear bumper step support bracket using the stock hardware. Use a 13mm socket to tighten. **See Photo 14.**
16. Reinstall rear bumper using stock hardware. **See Photo 15.** Make sure spare tire tube go back in bumper correctly.


PHOTO 14


PHOTO 15

17. Plug in the 7 way connector and bumper wiring. Tighten bumper using a 15mm, 18mm and a 21mm sockets. Make sure bumper is level
18. Reconnect battery

Kit Picture



Thank you for choosing Rough Country.