TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Skyjacker 9266 Installation Instructions

9000 Series Dual Steering Stabilizer for Ford Bronco (1966-1977)

Part number: 9266

trailfortress.com/skyjacker-9000-dual-stabilizer-kit-with-silver-cylinders-9266

Scan for fitment, price and install help

SKYJACKER SUSPENSIONS
SKYJACKER.COM

1966-1977 Ford Bronco 4WD Dual Steering Stabilizer Kit Installation Instructions

Required Tools List:

- **SAE Sockets \ Wrenches** (1/2", 9/16", & 11/16")
- **Adjustable Pliers**
- **Safety Glasses**
- **Wheel Chock**
- **Measuring Tape**
- **Torque Wrench**



Before beginning the installation, read these instructions thoroughly & completely. Please refer to the Parts List to insure that all parts & hardware are received prior to disassembly of the vehicle. If any parts are found to be missing, contact SKYJACKER® Customer Service at 318-388-0816 to obtain the needed items. If you have any questions or reservations about installing this product, contact SKYJACKER® Technical Assistance at 318-388-0816.

Important Notes:

- Fits 1966-1977 Models With Up to 2.75" Diameter Axle Tube.
  Tech Note: 1966-1971 DANA 30 = 2.50" Diameter. 1971-1977 DANA 44 = 2.75" Diameter.
- Fits 1966-1975 Models With OEM T-Style Steering Linkage. (See Page 2)
- 1976-1977 Models Must Have T-Style Steering Linkage Conversion. (See Page 2)

Component Box Breakdown:

Part # 2266

Item #	Description	Qty
2000AS	ADX HD STEERING DAMPER, ALU	2
ADXSD	DECAL, ADX 2.0 STABILIZER	2
HB-8266	HDWR BAG: 2266 / 8266 STAB.	1
7266-MB	MAIN BRACKET, CENTER AXLE	1

Part # 7266

Item #	Description	Qty
7000WS	STEERING DAMPER, WHITE	2
HYDRO 6X2-CL	DECAL, HYDRO STABILIZER	2
HB-7266	HDWR BAG: 7266 / 9266 STAB.	1
7266-MB	MAIN BRACKET, CENTER AXLE	1

Part # 8266

Item #	Description	Qty
8000BS	STEERING DAMPER, BLACK	2
MXSD	DECAL, BLACK MAX STABILIZER	2
HB-8266	HDWR BAG: 2266 / 8266 STAB.	1
7266-MB	MAIN BRACKET, CENTER AXLE	1

Part # 9266

Item #	Description	Qty
9000WS	STEERING DAMPER, SILVER	2
SSD	DECAL, SILVER STABILIZER	2
HB-7266	HDWR BAG: 7266 / 9266 STAB.	1
7266-MB	MAIN BRACKET, CENTER AXLE	1

Hardware Bag Breakdown:

Part # HB-7266

Item #	Description	Qty
HOURGLASS 5/8	HOURGLASS, 5/8 X 1.50, RED	4
140629	EB6 STUD, BAG # 141397	4
38X234X312U	3/8 X 2-3/4 X 3-1/2 U-BOLT, RD	2
38FSCTN	3/8 COURSE FLANGE NUT	4
516X1X134U	5/16 X 1 X 1-3/4 U-BOLT, RD	2
516X114X134U	5/16 X 1-1/4 X 1-3/4 U-BOLT, RD	4
516FSCTN	5/16 COURSE FLANGE NUT	8
7218-DB	TIE ROD BRACKET, DRIVER	1
7254-PB	TIE ROD BRACKET, PASSENGER	1

Part # HB-8266

Item #	Description	Qty
HG5815-K	HOURGLASS, 5/8 X 1.50, BLACK	4
140629	EB6 STUD, BAG # 141397	4
38X234X312U	3/8 X 2-3/4 X 3-1/2 U-BOLT, RD	2
38FSCTN	3/8 COURSE FLANGE NUT	4
516X1X134U	5/16 X 1 X 1-3/4 U-BOLT, RD	2
516X114X134U	5/16 X 1-1/4 X 1-3/4 U-BOLT, RD	4
516FSCTN	5/16 COURSE FLANGE NUT	8
7218-DB	TIE ROD BRACKET, DRIVER	1
7254-PB	TIE ROD BRACKET, PASSENGER	1

trailfortress.com/skyjacker-9000-dual-stabilizer-kit-with-silver-cylinders-9266